



Module connection to the BMW buttons

CAN wires are connected in parallel to K-CAN and K-CAN2 buses.
 CAN2 from module (yellow/black and blue/black) connected to K-CAN, CAN1 (yellow and blue) connected to K-CAN2
 Most convenient way to connect is near the ZGW module. ZGW pinout illustrated below.



Pic 1. ZGW pinout

Table 1

Pin#	Name	Colour
50	K-CAN H	Orange/Green
51	K-CAN L	Green
48	K-CAN2 H	Yellow/Red
49	K-CAN2 L	Yellow/Brown
39	+12V	Red/Blue
19	GND	Brown/Black

<http://www.carsystems.com.ua>
<mailto:support@carsystems.com.ua>